



Technical Update

New information about your Netfinity® IDE server

This Technical Update provides information to users of the Netfinity 1000, IDE model. This document addresses the following issues:

- IDE drive cabling
- Write through cache
- Support for Windows NT Server 4.0.

IDE drive cabling

An IDE hard disk drive is installed in bay 6 and a CD ROM drive is installed in bay 1. The IDE cable connected to the hard disk drive has one available connector. The IDE cable connected to the CD ROM drive has another available connector. You can use these available connectors to install two additional internal IDE devices.

Write through cache

The IDE drive has write through cache disabled as a standard configuration. This might affect performance in certain applications.

Support for Windows NT Server 4.0.

The IBM Netfinity 1000, IDE model supports only Windows NT Server 4.0

09N8246

Printed in the U.S.A.

© Copyright International Business Machines Corporation 2000. All rights reserved.

Note to U.S. Government Users — Documentation related to restricted rights —use, duplication or disclosure is subject to restrictions set forth in GSA ADP Schedule Contract with IBM Corp.

IBM reserves the right to change specifications or other product information without notice. This publication could include technical inaccuracies or typographical errors. References herein to IBM products and services do not imply that IBM intends to make them available in other countries. IBM PROVIDES THIS PUBLICATION AS IS WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some jurisdictions do not allow disclaimer of express or implied warranties, therefore this disclaimer may not apply to you.

IBM and Netfinity are trademarks of the IBM Corporation in the United States, other countries, or both.

Other company, product, and service names may be trademarks or service marks of others.